



## StowAway Rod Holder Instructions (025.41):

### Package Includes:

- 3 - Rod Tubes
- 1 - Inside Bracket
- 1 - Outside Bracket
- 3 - Oval Washers
- 6 - Round Washers
- 6 - Nuts
- 6 - Bolts

### Tools Needed:

- Phillips Screwdriver
- 7/16" Socket or Wrench

**[www.StowAway2.com](http://www.StowAway2.com)**

**800-943-5377**

## StowAway Rod Holder Instructions:

**1.** Position a tube against the outside bracket (A), with the larger mounting holes away from the bracket. Push a bolt through the outer hole, oval washer, inner hole, and bracket as shown. Cut the wire tie holding the oval washer and insert the second bolt through the matching holes as above.

**2.** Position the outside bracket and tube against the cargo rack railing. Place the inside half of the rod holder bracket against the railing so that the bolts go through the inside bracket (B). Add nut and washer and tighten lightly.

**3.** Install the two remaining tubes, repeating steps 1 & 2 above.

**4.** Position the rod holder at the desired angle and location, and fully tighten all hardware.

