



StowAway Wheel Kit Instructions (020.2)

Package Includes

- 2 – Wheel assemblies

Tools Needed

- Open end wrench
- Socket wrench

www.StowAway2.com

800-943-5377

StowAway Wheel Kit Installation:

1. Remove two mounting bolts closest to latch side of the box. The mounting bolts fasten the StowAway Carrier to the frame.
2. Position one wheel assembly under the frame as shown in Image 1 and thread the bolt back through the carrier, frame, and wheel assembly until tight. Repeat for second wheel assembly.

